


Quick installation guide for exit button 7460 and 7461

A permanent 12-24 VDC supply is required to operate the touchless series EXIT BUTTON, and provide all its functions below.

Contact





The EXIT Button is default with Time delay 0.3 s, time is adjustable up to ~30 s.

Time delay



VR1



-  Turn left short
-  Turn right long

The EXIT Button is default with sensitive distance adjustable (3-15 cm).

Sensitive distance



VR2

-  Turn left near
-  Turn right far


The product is based on Infrared technology. Consideration must be taken to where and how to mount the product to minimize external disturbances. For example:

- Do not face the infrared sensor directly into sunlight.
- Do not face the infrared sensor towards a window or glass walls
- Reflectors or clothing with reflectors can affect the infrared beams to increase the distance




Contact info

 Seriline AB

 Gustavslundsvägen 50
167 51 Bromma | Sweden

 +46(0)10-150 75 00

 info@seriline.com

 www.seriline.com